


TASCO SALES (AUST) PTY LTD

Rusan rings and mounts heights

All our rings and mounts height is measured from top of the rail/prism, or receiver housing (if it is direct mount) up to the bottom of the scope tube or bottom of the rail on the scope tube. So we do NOT measure height to the center of the riflescope tube.



If you need measure up to the center, than simply add half of the tube diameter to our BH

Examples:

<u>BH [mm]</u>	<u>Rings diameter [mm]</u>	<u>Height up to the center of the ring [mm]</u>
8	30	23 (8 + 15)
10	36	28 (10 + 18)
12	40	32 (12 + 20)

BH [mm]

6.5 *(ultra) low*

8/9 *low*

10/11/12/13 *medium*

14/15/16 *high*

17 and more *extra high*

T. 02 9938 3244 **W.** www.tasco.com.au **ABN.** 54 000 502 910

F. 02 9939 2972 **E.** sales@tasco.com.au Unit 6 Winbourne Estate, 9-13 Winbourne Rd, Brookvale, NSW 2100

Postal Address: PO BOX 6176, Frenchs Forest, NSW 2086